



400 E CLINTON PLACE | ST. LOUIS, MO 63122 | PHONE 314-822-1191

Subterranean Termite Treatment Preparation Instructions

Termite treatments require drilling through concrete around the perimeter of your structure to effectively treat the structure for termites. This is often a dusty and messy process. If you have any items that are valuable to you, please take care to remove them from the area before drilling begins. Also, please prepare your area for our crews to work before we arrive by following the bullet points below:

- Please clear inside perimeter of garage area to provide a three (3) foot area for our crew to work in.
- Remove any yard waste or items stored along the side of the outside perimeter of the structure. This includes wood piles and wood racks.
- Move any furniture items on concrete patios three (3) feet away from the perimeter of structure. If there is extra sensitivity about them getting dusty or dirty, you may want to move them away from the actual patio.
- Do not run sprinkler systems one day before and one day after service. Please make arrangements to have the sprinkler system turned off on the day of service as well.
- Plan for concrete areas to be patched. Please prepare to give the patched areas adequate time to dry and cure before moving personal items back over them.

Important Note:

Termites will still be alive for a period of time after the treatment. The product we are treating your home with is a non-repellant, which means that the termites pick up our product and get it to the queen of the termite colony to eliminate the source of your problem. It is not uncommon for the termites to live several days after treatment.